


BARTLETT CATERING EQUIPMENT MANUFACTURERS

PARTS LIST

**YEOMAN COOKER WITH CERAMAIC TOP
ELECTIC**

**MODEL:
F30E/932**

YEOMAN ELECTRICALLY HEATED COOKER
WITH CERAMIC TOP
F30E-932 16.03.99



Bartlett Catering Equipment Limited
Parts List

Model: Yeoman Range – F30E/932 (Electric)

Item	Part No	Description	Quantity
1	4434-210	Hob Assembly	1
2	3843-144	Round Hob Element	3
3	4434-312	Hob Fixing Plate	1
4	4434-330	Control Panel	1
5	4428-511	Door Catch Spacer	1
6	4428-510	Door Catch Plate	1
7	-	Not Required	-
8	3883-120	Ball Catch	1
9	4428-248S	Door Assembly (RH)	1
10	4409-412	Door Handle	2
11	4428-249S	Door Assembly (LH)	1
12	3879-281	Control Knob	6
	3834-123	Oven Control Stat	1
	3834-121	(Square Element) 16 amp Switch Stat	2
	3848-137	(Round Element) 13 amp Energy Reg	3
13	4428-925	Top Hinge RH	1
	4428-924	Top Hinge LH	1
14	4434-320	Baffle Plate	1
15		5/16" Zinc Washer	14
16	3912-120	Spring	14
17	4434-302	Locating Pin	14
18	3860-160	Door Seal (Two Piece)	1
	3860-161	Door Seal (One Piece – Introduced Feb 1999)	1
19	4428-928	Lower Hinge RH	1
	4428-927	Lower Hinge LH	1
20	4434-914	Shelf Hanger RH	1
21	4428-929	Oven Shelf	3

Bartlett Catering Equipment Limited
Parts List

Item	Part No	Description	Quantity
22	4434-913	Shelf Hanger LH	1
23	-	Not Required	-
24	3848-135	Feet	4
25	4434-305	Base Tray	1
26	4434-204	Motor / Element Mounting Plate	1
27	3871-111	Fan	2
28	3891-160	Spindle Nut	2
29	3864-225	Oven Element	2
30	3886-120	Fan Motor	2
31	3843-118	Square Element	2
32	4428-923	Rear Upstand	1
33	3932-169	Terminal Rail	1
34	3831-126	Contactor (30 amp)	1
	3850-123	Fuse 5 amp	1