



EP-1-2828 & EP-2-2828

Countertop Model Electric Pizza Oven

PARTS LIST



(EP-2-2828 Shown)

Model Number: **EP-1-2828** ☐

EP-2-2828 ☐

Serial Number: _____

Voltage

208V ☐ 240V ☐


230V ☐ 230/400V ☐

Phase

1 ☐

3 ☐

Exploded View



PARTS LIST

Item	P/N	Description	Item	P/N	Description	Item	P/N	Description
1	C4075X	Spring Adjustment Bracket	30	M1368X	Infinite Switch - 230V & 240V (EGO)	59	S3271X	Door Hinge Bushing
2	C5018K	Outer Back (EP-2)	31	M1371A	Contact, 208V, 25A, 4Pole, 60Hz	60	S6064X	Door Seal
3	C5019K	Outer Side (EP-2)	32	M1372A	Contact - 240V	61	T1287X	Baking Deck, Ceramic 27-3/4x27-3/4x3/4
4	C5020K	Outer Top (EP-2)	33	M1382X	Timer - 60 Minute	62	S1050U	Legs, 30"
5	C5025X	Component Bracket	34	M1384X	Timer - 15 Minute	63	S1310U	Legs, 16"
6	C5027X	Door Stop Bracket	35	M1481X	Thermostat 400°C	64	S1014X	Legs, 4"
7	C5029X	Control Panel w/o Timer (EP-2)	36	M1482X	Thermostat, Hi-Limit	65	U1043A	Nameplate-Bakers Pride 13 1/4"
8	C5035X	Steel Hearth (Baking Deck)	37	M1554A	Transformer, 12V (EP-1)	66	U1057A	Label, 4 Block Wiring
9	C5040X	Door Assembly - Solid	38	P1003X	Terminal Block - 3 Poles	67	U1183A	Label, Ground Symbol
10	C5041X	Door Assembly - Window	39	P1025X	Ground Lug	68	U1192A	Caution Hot Label, Bi-Lingual
11	C5050X	Door Hinge Assembly	40	P1045X	Snap Bushing, 2"	69	U1240A	Label, Unit For Use Only With...
12	C5055X	Door Handle Assembly	41	P1074X	Wire Clamp	70	U1257A	Label, International Symbol
13	C5056X	Door Stop Bracket	42	P1098X	Terminal Block	71	U1333A	Label, Warning (Pizza Oven/Cordierite)
14	C5058X	Control Panel w/Timer (EP-2)	43	P1192X	Circuit Breaker, 10A, 3Ph, 230/400V	72	U1364A	Label, Warning
15	C5078K	Back Cover (EP-1)	44	P1193A	Lamp Assy, Halogen, 12V, 20W	73	U1382X	Overlay - No Timer (EP-2)
16	C5080K	Control Panel (EP-1)	45	P1194X	Lamp-Halogen	74	U1383X	Overlay - 60 Minute Timer (EP-2)
17	C5082K	Side Covers (EP-1)	46	P1195X	Light Cover	75	U1395X	Overlay - 15 Minute Timer (EP-2)
18	L1193A	Lower Element - 230V 750W	47	P1201X	Circuit Breaker, 1Ph, 10A	76	U1433A	Overlay - 15 Minute Timer (EP-1)
19	L1194A	Upper Element - 230V 500W	48	P1207X	Din Rail, 7-3/4"	77	Q2301X	Shoulder Bolt
20	L1195A	Front Element - 230V 750W	49	P1208X	Circuit Breaker-3Ph, 25A, 208/240V	N/S	C5033K	Element Support Bracket
21	L1196A	Lower Element - 208V 750W	50	P1210E	Din Rail, 9-3/4"	N/S	C5044K	Glass Retainer
22	L1197A	Upper Element - 208V 500W	51	U4186A	Manual, Installation/Operation	N/S	S6073A	Ceramic Fiber Strip, Adhesive, (1" x 25')
23	L1198A	Front Element - 208V 750W	52	S1062A	Terminal Cap, 10-32	N/S	X1121Q	Packaging
24	L1199A	Lower Element - 240V 750W	53	S1306X	Knob, Rotary Sw, w/Brass Insert (w/M1282A)	N/S	P6399A	Line Cord
25	L1200A	Upper Element - 240V 500W	54	S1311S	Knob, Thermostat/Timer, Alum Inlay	N/S	T8085T	Open Rack Stand (w.o. 30" Legs)
26	L1201A	Front Element - 240V 750W	55	S1403X	Knob, 1 1/4"			
27	M1352X	Switch, Rocker, Green	56	S1404A	Glass, Door Window 4" x 20"			
28	M1360X	Transformer, 24V (EP-2)	57	S3004X	Spring, Door, 13/16 x 6-3/4"			
29	M1367X	Infinite Switch - 208V (EGO)	58	S3007X	Spring Bushing, Teflon			N/S = Not Shown



EP-1-2828 & EP-2-2828

Countertop Model Electric Pizza Oven