












ANO.EU.00014
Upper-Back Cover
Inox EU40




ANO.EU.00009
Door for EU40
Handle ANO.00.00119

































HLE.00.00168
Tank Thermofuse 90C


YDR.00.00178
Pump's outlet
Pipe (Z)

YDR.EU.00019
Wash Pump
Output Hose
Φ18 EU40

HLE.00.00184
Tank Draining Pump

YDR.00.00014
Draining's Pump
inlet Pipe









HLE.EU.00000
Wiring for EU40


HLE.00.00180
Thermofuse Boiler
99C



HLE.00.00260
Boiler Element
Fiting Base



HLE.00.00004
Heater Element
Cover




HLE.EU.00006
Heater Elem. Boiler 2.5kW



ANO.EU.00026
Boiler for EU40



HLE.EU.00009
Control Panel Complete with Buttons



HLE.00.00009
Power Switch without Draining Pump

HLE.00.00137

Power switch with Draining Pump

HLE.00.00028, Indicator Orange

HLE.00.00176, Indicator Green

HLE.00.00399, Start Button