



PARTI DI RICAMBIO  
 PIECES DETACHEES  
 SPARE PARTS  
 ERSATZTEILE  
 LISTA DE RECAMBIOS

**AC**


4/98




**AC 91**  
**AC 101**




**AC 122**




**AC 151**  
**AC 152**





**AC 181**  
**AC 182**



**AC 201**  
**AC 202**




**AC 241**  
**AC 242**



10 - 1998 S. AG.


## AC91

### Wash Hood



**AC91**


**Wash Tank Components**






**AC91**

**Wash Assembly AC91 - AC101**






**AC91**

**Upper Wash Arms/Lower Wash Arms AC91 - AC101**




LAVAGGIO INFERIORE  
braccio sinistro/destro



**AC91**



**Rinse Assembly / Boiler with 1 heating element**






**AC91**

**Economiser/micro switches**




10 - 1998 S. AG.

**AC91**  
Drive unit





**AC91**  
Drive unit



**AC91**

**Control Box AC91 - AC101**

