
Product no.: **0-S3710718A010796**

Model **:** **FKG 371**

GB - Spare parts list


D - Ersatzteilliste

F - Liste des pieces detachees

E - Lista de piezas de recambio

NL - Lijst van reservedelen

DK - Reservedelsliste



Pos. No.	Code No.	GB Part	Price Code
0001	0-70381100103	Thermometer, refrigerator	0-G7
0002	0-7038080	Glow lamp - green	0-H3
0005	0-7038257	Thermostat, refrigerator	0-Y5
0006	0-52382970203	Control panel	0-N3
0008	0-2038011	Screw	0-D2
0011	0-70380670303	Switch	0-F4
0012	0-20380210103	Screw, black	0-B2
0013	0-A1510100403	Switch for light, Bow	0-N3
0014	0-52380410103	Thermostat knob, complete	0-E3
0017	0-523810804	Cover for electrical unit	0-E3
0019	0-543834301	Strip for top panel "VESTFROST"	0-E5
0020	0-52381290203	Covering	0-P2
0025	0-6238149	Condenser	0-P7
0027	0-2538145	Nut, M4 DIN 562	0-A2
0030	0-A1040010103	Hinge, "R"	0-F3
0040	0-5238112	Contact face for hinge	0-F3
0049	0-5238025-01	Holder for condenser	0-K2
0061	0-6538053	Filter drier, 20 g	0-V3
0067	0-5235002	Castor, complete	0-D3
0070	0-A921001	Cover + wirring clamp	0-E3
0072	0-5238224	Distance piece	0-E2
0073	0-2538195	Counter nut for hinge	0-V2
0086	0-3038005	Washer plate	0-A2
0087	0-6038175	Base plate fittings, set, complete	0-H3
0090	0-523802402	Suspension	0-K2
0094	0-5238133	Contact face for hinge	0-F3
0095	0-2038025	Screw	0-B2
0096	0-52382870101	Covering - White	0-A2
0121	0-52386460103	Lamp chimney	0-B3
0122	0-5238404	Housing for fittings for phial	0-H2
0123	0-5238403	Fittings for phial	0-H2
0129	8-036038480	Compressor - FR 8,5 G, Refrigerator, Complete, R134a	1-J13
0144	0-5238226	Holder for evaporator	0-R2
0153	0-A129702	Mains lead	0-K4
0154	0-7038254	Cover for multiple plug	0-F3
0166	0-5238525	Lamp chimney	0-Y4
0186	0-703867001	Fan, 230v-60Hz.	0-G8
0187	0-A40600201	Fan	0-F8
0188	0-7038082	Fluorescent tube, 15W, 220V	0-D6
0189	0-A419002	Fixtures	0-U7
0190	0-953880201	Strip for lamp glass, "VESTFROST"	0-G4
0191	0-7038094	Coil, Optima 28/type D15-302, 220V	0-O4
0194	0-6938086-01	Wire shelf	0-U4
0196	0-A9156020040203	Lock complete	0-N5
0199	0-483823402	Key, set - 2	0-A3
0200	0-52385350103	Support for door	0-A3
0201	0-52385610103	Lock fittings	0-E3
0238	0-7038103	Glow switch, 4 - 20W	0-X2
0244	0-A11011815	Door, complete, glass	0-N11
0297	0-52381280103	Cover plate for control panel	0-Y4
0322	0-52389850103	Grate	0-L3
0324	0-52384170101	Cover for fan	0-P6
0380	0-5238298	Evaporating tray	0-Y3
0383	0-52390720203-01	Rubber fillet	0-X6
0392	0-52388750103	Hand lever, complete	0-E5
0406	0-6738028	Evaporator	0-M8
0426	0-7038486	Starting device	0-C6
0442	0-6216200	Heat tubing-FR	0-A5
0506	0-A1040010303	Hinge	0-J3
0550	0-7038477	Starting condenser 117U5015	0-V3
0602	0-2038042	Locking ring	0-G2
0623	0-6938166-01	Wire shelf	0-U4
0709	0-52391220103	Bush	0-D2
0715	0-2038053	Screw	0-A2
0718	0-7038407	Socket	0-M2
0869	0-5238956	Ajustable foot	0-P2



FKG 371

3.2

Pos. No.	Code No.	GB Part	Price Code
0890	0-5238960	Contact face for hinge, left + right	0-J3
0986	0-A1040040203	Bottom panel, skirting board	0-R3
0997	0-7038406	Socket	0-M2
0998	0-4238184	Clips	0-D2
1022	0-5238496	Defrost water seal	0-S3
1071	0-4838096	Pivot	0-B3

Please Note!

The drawing covers all variants of the model and therefore contains more pos. numbers than your product. See the spare parts list for exact product specification.



-	230 V			115 V	
	Farvekode	Colour Code	Farbkode	Colour Code	
				New	Old
BN	Brun	Brown	Braun	Brown	white
BU	Blå	Blue	Blau	Blue	Black
BK	Sort	Black	Schwartz	Black	Blue
Li	Lilla	Lilac	Lila	Lilac	Brown
YE-GN	Gul/Grøn	Yellow/green	Gelb/grün	Green	Green
WH	Hvid	White	Weiss	White	White
RD	Rød	Red	Rot	Red	Red

Wire - diagram

10.06.099 - B

FKG - 110V og 230V