




N°	Code	Description	Values	Price
1	113.01/15	Helix pin		
2	113.02/02	Blade		
3	113.02/01 4,5	Plate ø 4,5		
4	113.04/04	Ring nut		
5	122.01/30	Locking body		
6	122.01/32	Locking lever		
7	122.01/31	Counter-piece		
8	122.02/11	Nut	M8	
9	116.01/01	Mouth		
10	113.04/06	Helix		
11	116.04/04	Hopper		
12	750.03/04	Microswitch		
13	122.02/13	Screw	M5 x 16	
14	116.01/06	Fastening ring		
15	110.01/15	Pestle mod. 32		
16	116.01/13	Ring locking key		
17	116.04/03	Wiring diagram cover		
18	122.01/36	Distance piece		
19	311.03/17	Box	GW 44206	
20	122.03/06	Electronic board		
21	130.03/18	Contact		
22	110.02/06	Bearing	6005- 2Z	
23	116.02/01	Bearing	7205 - BE	
24	116.02/02	Sealing ring		
25	116.02/05	Key	6 x 6 x 15	
26	116.01/09	Shaft		
27	116.04/01	Cover		
28	116.01/04	Support		
29	116.01/14	Screw		
30	310.02/29	Screw	M8 x 30	
31	122.01/13	Pin stop plate		
32	122.02/10	Screw	M5 x 8	
33	116.01/11	Safety cover		
34	410.02/07	Screw	M8 x 35	
35	122.01/26	Foot +rubber washer		
36	750.02/48	Washer		
37	122.02/12	Screw	M6 x 50	
38	130.03/23	Cable presser		
39	116.02/06	Screw	M6 x 16	
40	116.01/03	Gear set		
41	116.02/03	Cable		
42	122.02/07	Split pin		
43	122.02/02	Notched nut	M16 x 1,5	
44	122.02/04	Cup spring		
45	122.02/03	O - Ring	117 NB70	
46	116.01/07	Gear pin		
47	310.02/13	Screw	M8 x 20	
48	310.02/24	Washer		
49	116.02/07	Key	8 x 7 x 20	
50	116.05/02	Motor 1 ph	V230 / 50Hz	
51	116.05/03	Capacitor		
52	122.01/21	Plug		
53	116.01/05	Gearbox		
54	132.04/05	Nut	M8	
55	130.03/15	Cover		
56	130.03/11	Push button		
57	130.03/12	Stop/emergency button		
58	130.03/19	Pilot lamp	24V	
59	130.03/09	Push button		
60	900.03/22	Contact		
61	116.01/15	Pin		
62	122.02/15	Plug		
63	116.02/04	Fuse	13A	