


CD13.



Item	Qty	Part N°	Description
1	1	12432	Table
2	1	10529	Tray
3	1	12126	Filter / Filter
4	1	17963	Component bracket
5	2	3505	Screw / H M6 x 12
6	1	12152	Single phase terminal block
	1	12153	3 phase terminal block
	2	12112	Screw / C M3 x 12
	2	3765	Washer / DE 3
	2	25173	Nut / Hu M3
7	1	17964	Contact bracket
8	1	9766	Contact / 230V
	1	3328	Contact / 230-400V
	2	3572	Screw / C M4 x 16
	2	3780	Washer / Cs M4
	2	3651	Nut / Hu M4
9	1	6572	Grommet
10	2	12151	Collar screw / H M6 x 16
11	1	17961	Base plate
12	1	3108	Seal
13	2	3563	Screw / FB M6 x 25
14	1	3312	Timer
	1	1108	Timer seal
	2	3532	Screw / F M4 x 10
	1	17971	Timer plate
	1	5188	Timer knob
15	1	3682	Rivet / CTR 1 2 x 5
16	1	17927	Push button START-STOP
	1	12562	Earth washer
17	1	3177	seal / ø 3
18	1	17952	Component housing
19	1	17908	Spacer bush
20	1	17955	Bush / 22 x 27 x 28
21	1	1964	Key / A 5 x 5 x 20
22	1	3570	Screw / C M4 x 8
	1	3766	Washer / DE 4
23	1	16675	Earth terminal
24	1	17910	Shaft DS 17317
25	1	17958	Outlet pipe
26	1	1410	Collar / 50-70
27	1	17948	Bulkhead
28	3	3512	Screw / H M6x30
	3	3785	Washer / Cs M6
29	1	1189	Right handle
30	1	17917	Handle tube
31	1	1190	Left handle
32	2	5086	Pin / G05 10 x 32
33	2	1207	Ring / 10 x 14 x 15,5

34	1	17913	Door
35	2	4271	Ring / 8 x 11,9 x 15
36	1	17914	Door seal
37	2	20185	Door locking pin
	2	3785	Washer / Cs M6
	2	3512	Screw / H M6x30
38	1	17915	Pin / G06 8 x 75
39	1	17943	Cylinder
40	1	17918	Hopper cover
42	1	17968	Jet
	1	17945	Nut / 1/2 gaz
43	1	17970	Abrasive plate
44	2	17954	Knob
	2	17953	Bolt / M 10 x 20
45	1	17911	Deflector
46	1	3117	"O" ring / 17,12x2,62
47	1	5628	Pin / G06 8 x 45
48	1	3020	Belt / 559 J6
49	4	3509	Screw / H M6 x 20
	4	3785	Washer / Cs M6
50	1	17962	Motor bracket
51	1	5060	Screw / H M6 x 35
52	1	10254	Plug
53	4	5093	Screw / H M8 x 20
	4	9015	Washer / Cs M8
54	1	3502	Screw / H M5 x 25
55	1	17906	Drive pulley
	1	1964	Key / A 5 x 5 x 20
56	1	17950	Motor
57	1	17950	Body
58	4	5093	Screw / H M8 x 20
	4	9015	Washer / Cs M8
59	1	2476	Cable stand
	1	3479	Lock nut
60	1	11573	Power supply cable / 3 x 1 mm²
	1	3404	Power supply cable / 4 x 1 mm²
61	3	3774	Washer / W6
	3	3653	Nut / Hu M6
62	1	3041	Bearing / 6203 2RS
63	1	3073	Circclip / 40i
64	1	18290	Driven pulley
65	1	9032	Washer / M12
	1	3676	Nut myloc / M12
66	4	7637	Screw / ST M6 x 35
	4	3782	Washer / Cs L6
	4	3653	Nut / Hu M6
67	1	12151	Collar screw / H M6 x 16
68	4	4338	Square nut
69	4	12128	Foot
70	4	5319	Screw / H M6 x 45
	4	3782	Washer / Cs L6

Parts
000631,

DS 17316 Bearing Housing APS
DS 17317 START ARM

56- Motor 1PA. 000594 E193.34

000636 HANDLE ARM. 29,30,31.

000591. Door ARM. (Door/Seal/Bulb)