



Parts List & Exploded View



Ref.	Part No.	Description	Ref.	Part No.	Description
1	537-711	Front Cover	24	537-335	RH Upright
2	537-711	Bun Chute	25	537-684S	Platen
3	537-725S	Rubber Belt	26	537-337	Insulation
4	537-330S	Conveyor Assy.	27	537-296	Heater Housing
5	537-338	Base Pad	28	537-366	Heater Housing Plate
6	537-320	Bottom Plate	29	537-409	Rear Panel
7	537-373	Ramp Baffle	30	537-332	RH Cover
8	87-028TXCS	Motor	31	537-396	Bun Thickness Overlay
9	88-577S	Fuse Block	32	537-476S	Hi-Temperature Switch
	88-578S	Fuse (Pkg. of 2)	33	537-343S	PC Board & Overlay Assy.
10	537-383	Retainer Bar Lower	34	537-603	RH Cam Shaft
11	537-398	Retainer Bar Upper	35	537-299	RH Slide Plate
12	537-403-3S	Teflon Sheet (Pkg. of 3)	36	65-058	Heater Relay
	537-447	Teflon Conversion Kit	37	537-295S	Heater
13	537-333	LH Cover	38	86-355S	Sprocket
14	537-395	Bun Crush Overlay	39	537-735S	Idler Sprocket & Bracket Assy.
15	70-050	Bun Crush Adj. Knob	40	537-348S	Sprocket
16	537-298	Cam Bracket			
17	537-379	Guide Bracket	42	66-034	Strain Relief
18	537-717	LH Cam Shaft	43	72-373S	Power Cord
19	537-300	LH Slide Plate	44	537-729S	Drive Chain & Sprockets Kit
20	537-381	Conveyor Bracket	45	65-048-14	Power Relay
21	537-382	Conveyor Bracket	46	537-388S	Transformer Assy.
22	537-319	Ramp	47	537-400	Temperature Probe
23	537-336	LH Upright			

Parts List & Exploded View



Ref.	Part No.	Description	Ref.	Part No.	Description
1	537-351	Frame	10	537-411	Upper Roller
2	537-354	Air Shield	11	537-315	Upper Shaft
3	537-349	Cross Brace	12	537-317S	Upper Bearing (Package of 2)
4	537-412	Lower Roller	13	79-055S	Washer (Package of 2)
5	537-370S	Lower Bearing (Package of 2)	14	81-017S	Spring (Package of 2)
6	537-318S	Lower Shaft (Short)	15	86-272S	Cotter Pin (Package of 2)
7	537-316S	Lower Shaft (Long)	16	69-011S	Rivet (Package of 4)
8	197-279	Pin	17	76-640	Screw
9	537-334	Slide Bracket			