

Spare parts list



**No tariff
version
2009**

www.dynamicmixers.com

Dynamic
The original!

MIXERS

	Page
DYNAMIX	5
MD 95	6
JUNIOR STANDARD	7
JUNIOR PLUS	8
MMX 92	14
MMX 98	15
PMX 83	16
PMX 98	17
PMDH 250	18 & 19
MX 79	20
MX 85	21
MX 91	22
MX 2000	23
MDH 460	24 & 25
MDH 2000	26
MX 2000 DSC 230 V - 50 Hz	27
MX 2000 DSC 230 / 115 V - 50 / 60 Hz	28
SMX 450	40 & 41
SMX 500	42 & 43
SMX 502 - 600	44 & 45
SMX 600 E	46 & 47
SMX PRO 600 DSC	48 & 49
SMX 800 E	50 & 51
SMX PRO 800 DSC	52 & 53

CORDLESS MIXER

MXP 94 - Mini cordless mixer	12
------------------------------	----

WHISKS

JUNIOR WHISK	10
FD 98	11
FT 97	29
FT 86	30
FT 79	31

CORDLESS WHISK

FTP 94 - Mini cordless whisk	13
------------------------------	----

MULTI-FUNCTION

JUNIOR COMBI	8 & 9
PMF 250	18 & 19
MF 90	32 & 34
MF 2000	33 & 34
MFAP 90	32 & 34
MFAP 2000	33 & 34

RICER

PP 84	36
PP 97	37
PP 97 +	38 & 39

ACCESSORIES

RICER TOOL AP 90 / FM 90	35
ICE CREAM MIXER TOOL GP 2000	25

CITRUS JUICER

PA 96	54
-------	----

GIRAFE-MIXER

GM 93	55
-------	----

SALAD SPINNERS

ELECTRIC SALAD SPINNER EM 98	56
MANUAL SALAD SPINNER E 10	57
MANUAL SALAD SPINNER E 20	57
MANUAL SALAD SPINNER E 20 SEALED COVER	58 & 59

SUPPORTS

SM4, SM6, SM8, SM10, SM12	54
---------------------------	----

VEGETABLE CUTTERS

FOOD CUTTER CF 2000	55
DYNACOUPE	60
DYNACUBE	61

CUTTER

DYNA CUTTER	62 & 63
-------------	---------

VS ATTACHMENT

VS ATTACHMENT	64 & 65
---------------	---------

TERMS AND CONDITIONS

(General freight and payment terms)

Freight charges are not included in prices. Unless indicated, all export shipment terms are EX-WORKS. All shipments, including Franco, are at customers or carriers risks.(art.105 Commerce Code). Freight carrier remains at the discretion of Dynamic, unless when carrier is chosen by the customer. Damage claims must be made within 72 hours from shipment arrival. This price list is effective for year 2009 and it supersedes all previous ones. All invoices will show net prices without any additional discounts. Invoices are payable to Dynamic France, Z.I du Puy Nardon, 85290, Mortagne- sur-Sèvre, France. Prices are subject to change without notice. At the exception of existing company accounts, all orders must be paid before shipment (bank transfer), based on the supplied proforma invoice. For more further please contact us directly.

BANK TRANSFER INFORMATION :

Caisse de Crédit Mutuel de Mortagne sur Sèvre.
36 Rue Nationale - 85290 Mortagne-sur-Sèvre, France.
IBAN : FR 1551 9851 1700 0099 8903 138
Bank code : 15519
Desk code : 85117
Account number : 00009989031
Rib Key: 38
BIC/SWIFT : CMCIFR2A

RETURNS : Returns require prior written or verbal authorization from commercial Head Office. Non-authorized returns, will be sent back to the originator, collect. All returned merchandise are subject to a 10% re-stocking charge. Special items (non standard) are not refundable. Ownership rights. In conformity with Article 65, Code 67-563 modified under article 80-335, dated May 12th 1980, the following final terms will be applied to all orders :

1) All faulty payments including partial payments will cancel terms negotiated and make all amounts due, immediately payable to Dynamic France. Furthermore, it is also agreed that all sold

merchandise remain the property of Dynamic France until full payment.

2) All invoices are payable to Dynamic France in Mortagne-sur-Sèvre, any discrepancies will be directly handled by Tribunal du Commerce , Roche-sur-Yon, France.

SPARE PART ORDERS :

The following information must be included with all spare part orders :

Clear and complete customers information.

Machine model number.

Machine serial number.

Spare part description and catalogue reference number.

UNDER WARRANTY AFTER SALES SERVICE CONDITIONS :

Please refer to your nearest service center or contact our commercial head office for further information:

Dynamic France - ZI du Puy Nardon
85290 Mortagne Sur Sèvre, France
Phone (33) 2 51 63 02 72
Fax (33) 2 51 63 02 73
email : contact@dynamicmixers.com

For regular service requests (out of warranty). Defective machines have to be carried into the service center at customers' expenses. In all cases a complete appraisal will be done and returned to the customer, via fax, email or by phone, before any repairs for approval. Labor rate: a standard labor rate of 32.00 € / Hr. will be applicable to all repairs not under warranty. Six month warranty period on service work completed by Dynamic. Appraisal fees of 32.00 € (labor, re-assembling and packaging) will be applied for declined estimates on machines you request to be re-assembled and not repaired.

WEEE (Directive on Waste Electrical and Electronic Equipment): In so far as the equipment sold is professional electrical and electronic equipment referred to in Decree 2005-829 of 20 July 2005, transposing Directive 2002/96/EC of 27 January 2003, it is agreed that the buyer in possession of this equipment shall, in the absence of an agreement to the contrary, be responsible for financing and organising disposal of waste from this equipment under the conditions defined in Articles 21 and 22 of the said decree. In the event of an inspection, the constructor may ask the buyer to send documents confirming that he has met all the obligations for this equipment transferred to him by virtue of the contract of sale. If these documents are not sent, it will be assumed that the customer has failed to carry out the obligations incumbent on him and the manufacturer reserves the right to ask him for reparation of any damage he may suffer as a result of this. In accordance with Article 6 of Decree 2005-829 of 20 July 2005, marking indicating the producer's identity and the marketing of the equipment after 13 August 2005 appears

on all equipment. The producer has registered with the national register of producers (ADEME for France). According to the legal measures in force, the customer assuming the obligations for disposal of the waste must ensure that selective treatment, recycling and destruction of selectively collected waste electrical and electronic equipment is carried out at facilities meeting the technical requirements set by the Order of 13 March 2006 and Decree 2005-829 (Article 23) or at any other facility authorised for this purpose in another member state of the European Union or in another state on condition that this waste is transferred outside France in compliance with the measures of the afore-mentioned regulation of February 1st 1993. Ensure that technical operations for collection and selective treatment of materials and components of waste electrical and electronic equipment are correct and that all fluids have been extracted, in compliance with the requirements or the order. Ensure that the information concerning the collection and treatment of this waste is passed on to any later buyer.

Parts list


Code

Cover or handle screws (2)	079958	
Cover	2840	
Hook	2841	
Power cord	2842	
Right handle	2843	
Shaft and bearing	2844	
Foot assembly + ring + seal	2845	
Coupling	2846	
Motor 230 V	2847	
Dynamic label	2848	

Parts list

Code

Left handle	2849	
Screws + washer + handle nuts (2)	2850	
Hood	2851	
Circuit board	2852	
ID label (230V)	2853	
Motor belt	2854	
Screws for motor belt	2855	
Emulsifying blade	9414	
Handle cap protectors	45710	




MD 95 MIXER

Parts list

Code


Waterproof seal	0632	
Self-lubricating ring	0637	
Hook	0863	
Complete stainless steel shaft + coupling	089956	
Non-locking switch	0908	
Filtering Capacitor	0909	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Dynamic label	1027	
Brace screws (4)	8317	
Emulsifying blade	9414	
Cutter blade w/screws	9415	
Power cord 230 V	9501	
Power cord 115 V	9501.1	
Handle screws (3)	9502	
Lower handle w/ label 230 V	9503	
Lower handle w/ label 115 V	9503.1	
Upper half handle	9504	
Complete handle 230 V (w/ sticker, screws, logo, switch, strain relief, power cord)	9505	
Complete handle 115 V (w/ sticker, screws, logo, switch, strain relief, power cord)	9505.1	
Braces (4)	9506	
Motor & screw & capacitor 230 V	9507	
Motor & screw & capacitor 115 V	9507.1	
Coupling sleeve	9508	
Motor holder w/ 4 screws	9509	
Foot assembly w/ bearing (exc. shaft + blade)	9510	
Carbon brushes (2) 230 V	9512	
Carbon brushes (2) 115 V	9512.1	




Parts list

Code

Motor 230 V	0535	
Motor 115 V	0535.1	
Waterproof seal	0632	
Self-lubricating ring	0642	
Stainless steel shaft + coupling	0870	
Bearing only	0898	
Wall bracket	089959	
Non-locking switch	0908	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Dynamic label	1027	
Label w/ serial number 230 V	1081	
Label w/ serial number 115 V	1082	
Complete handle 230 V	4000	
Lower half handle w/ label 230 V	4001	
Lower half handle w/ label 115 V	4001.1	
Upper motor housing	4002	
Foot assembly w/ bearing (exc. Shaft + blade)	4003	
Cutter blade	4004	
Braces (4)	4005	
Ball bearing ring	4006	
Coupling sleeve	4007	
Filtering capacitor	4008	
Carbon brushes (2) 230 V	4050	
Carbon brushes (2) 115 V	4050.1	
Brace screws (4)	7903	
Power cord 230 V	9011	
Power cord 115 V	9040	
Power cord (Australian)	9066	
Power cord (English)	9067	
Handle screws (3)	9502	
Upper half handle	9812	
Switch protector	9813	



089959




JUNIOR PLUS AND JUNIOR COMBI MIXERS

Power Unit

Parts list

Code

Stator 230 V	0535
Stator 115 V	0535.1
Wall bracket	0880.1
Non-locking switch	0908
Strain relief 230 V	0950
Strain relief 115 V	0950.1
Dynamic label	1027
Id label (Junior Plus) 230V	1084
Id label (Junior Plus) 115V	1085
Id label (Junior Combi) 230V	1086
Id label (Junior Combi) 115V	1087
Speed variator 230V	1213
Speed variator 115V	1214
Upper motor housing	4002
Braces (4)	4005
Ball bearing ring	4006
Complete handle w/ power cord 230V	4010
Complete handle w/ power cord 115V	4010.1
Lower half handle w/ Junior Plus label 230V	4011
Lower half handle w/ Junior Plus label 115V	4011.1
Filtering capacitor	4012
Coupling	4013
Speed variator knob	4014
Lower aluminium motor housing	4015
Complete handle w/ power cord 230V	4030
Complete handle w/ power cord 115V	4030.1
Lower half handle w/ Junior Combi label 230V	4031
Lower half handle w/ Junior Combi label 115V	4031.1
Carbon brushes (2) 230 V	4050
Carbon brushes (2) 115 V	4050.1
Brace screws (4)	7903
Power cord 230 V	9011
Power cord 115 V	9040
Power cord (Australian)	9066
Power cord (English)	9067
Handle screws (3)	9502
Switch protector	9813
Upper half handle Junior Plus & Junior Combi	9832
Complete motor block (see machine catalogue)	AC100



Complete foot assembly

Parts list

Code



Waterproof seal	0632
Self-lubricating ring	0642
Bearing only	0898
Cutter blade	4004
Foot assembly with bearing	4016
Kit w/ shaft lower ball bearing and coupling	4017
Ball bearing ring	4018
Coupling hub	45123
Complete Junior foot (see machine catalogue)	AC101

Whisk tool

Parts list

Code

Ball bearing	0601	
Pins 3 x 10	0638	
Pins 3 x 14	0745	
Open head locking washer (unit)	0766	
Entry gear	0837A	
Lower motor whisk housing	4019	
Equipped upper shaft (complete)	4020	
Plate w/ seals and screws	4021	
Holder assembly screws (4)	4022	
Reduction gear assembly	4025	
Middle gear & shaft	9420	
Equipped output axle w/ 2 gears+pins	9421	
Holder assembly w/ 3 self-lubricating rings	9422	
Whisk tool (2)	9424	
Coupling hub	45123	
Upper driving shaft	089947	
Complete Junior Whisk tool (see machine catalogue)	AC102	






JUNIOR WHISK MIXER

Parts list

Code

Motor 230 V + Gear	0535.2
Motor 115 V + Gear	0535.3
Pin 3x14	0745
Non-locking switch	0908
Strain relief 230 V	0950
Strain relief 115 V	0950.1
Dynamic label	1027
Speed variator 230 V	1213
Speed variator 115 V	1214
Upper motor housing	4002
Braces (4)	4005
Ball bearing ring	4006
Filtering capacitor	4012
Speed variator knob	4014
Plate w/ seals and screws	4021
Holder assembly screws	4022
Lower half handle w/ Junior Whisk label 230 V	4040
Lower half handle w/ Junior Whisk label 115 V	4040.1
Lower aluminium motor housing	4041
Complete handle Junior Whisk 230 V	4042
Complete handle Junior Whisk 115 V	4042.1
Carbon brushes (2) 230 V	4050
Carbon brushes (2) 115 V	4050.1
Brace screws (4)	7903
Power cord 230 V	9011
Power cord 115 V	9040
Power cord Australian	9066
Power cord English	9067
Middle gear & axle	9420
Equipped output axle w/ 2 gears+pins	9421
Holder assembly w/ seals & washer	9422
Whisk tool (2)	9424
Handle screws (3)	9502
Switch protector	9813
Upper half handle	9832
Label w/ serial number 230 V	1099.10
Label w/ serial number 115 V	1099.11
Wall bracket	089959
Gear + Pin	089972





Parts list

Code


Pin for gear	0638	
Enter gear	0837	
Non-locking switch	0908	
Capacitor	0909	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Dynamic label	1027	
ID label 230 V	1059	
ID label 115 V	1060	
Speed variator w/ knob 230 V	1213	
Speed variator w/ knob 115 V	1214	
Brace screws (4)	8317	
Whisk connection box w/ 3 rings	9418	
Middle gear & axle	9420	
Output axle	9421	
Holder assembly w/ 3 self-lubricating rings	9422	
Whisk tool (2)	9424	
Power cord 230 V	9501	
Power cord 115 V	9501.1	
Handle screws (3)	9502	
Upper half handle	9504	
Braces	9506	
Half handle label side 230 V	9801	
Half handle label side 115 V	9801.1	
Complete handle 230 V (w/ variator, power cord, switch and strain relief)	9802	
Complete handle 115 V (w/ variator, power cord, switch and strain relief)	9802.1	
Motor holder	9803	
Motor support w/ 4 screws 230 V	9804	
Motor support w/ 4 screws 115 V	9804.1	
Variator knob	9806	

MXP 94 MINI CORDLESS

Parts list

Code


Waterproof seal	0632	
Self-lubricating ring	0637	
Handle screw (1)	0702	
Locking washer	0713	
Non-locking switch	0908	
Dynamic label	1027	
Brace screws (4)	8317	
Half handle (label side)	9401	
Upper half handle	9402	
Clips (2)	9404	
Braces (4)	9407	
Motor	9408	
Fan (coupling)	9409	
Motor holder + screws	9410	
Main shaft + locking washer	9411	
Emulsifying blade	9414	
Cutter blade w/ screw	9415	
Complete handle	9430	
Foot assembly w/ bearing (exc. shaft + blade)	9510	




**Mini cordless since :
01/01/2002**



Charger and battery
See machine catalogue





Parts list

Code

Handle screw (1)	0702	
Non-locking switch	0908	
Dynamic label	1027	
Holder assembly screws	4022	
Brace screws (4)	8317	
Lower half handle (label side)	9401.1	
Upper half handle	9402	
Clips (2)	9404	
Braces (4)	9416	
Motor & gear	9417	
Whisk connection box w/ 3 rings	9418	
Middle gear & axle	9420	
Equipped output shaft w/ 2 gears + 2 pins	9421	
Holder assembly w/ seals & washer+D331	9422	
Whisks (2)	9424	
Complete handle	9431	




Charger and battery
See machine catalogue


MMX 92 MINI MIXER

Parts list

Code

Carbon brushes (2)	0514	
Ball bearing	0601	
Self-lubricating ring	0604	
Waterproof seal	0607	
O. ring	0611	
Motor self-lubricating ring	0829	
Hook	0860	
Stainless steel bell	0894	
Non-locking switch	0908	
Filtering capacitor	0909	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Braces (4)	7913M	
Power cord 230 V	8303	
Power cord (English)	8303.1	
Power cord 115 V	8303.2	
Power cord (Australian)	8303.3	
Complete Motor 230 V	8304	
Complete Motor 115 V	8304.1	
Rotor 230 V	8304.12	
Rotor 115 V	8304.13	
Stator 230 V	8304.22	
Stator 115 V	8304.23	
Upper motor housing (w/ carbon brushes support)	8315	
Brace screws (4)	8317	
Lower motor housing	8318	
Handle cover w/ screws	8319	
Deflector	8320	
Ground wire	8321	
Screws w/ ground washer	8322	
Fan	8323	
Complete handle w/ slot for speed control knob 230 V	8601	
Complete handle w/ slot for speed control knob 230 V	8601.1	
Handle only w/ hood and screws	8602	
Variable speed control board 230 V	8608	
Variable speed control button	8609	
Shaft	9209	
S.S. lower bearing assembly	9210	
Motor housing w/ tube assembly	9211	
Cutter blade w/ screw	9213	
Variable speed control board 115 V w/ knob	9219	





Parts list

Code

Carbon brushes (2)	0514	
Ball bearing	0601	
Waterproof seal	0607	
Squeezing washer	0726	
Non-locking switch	0908	
Capacitor	0909	
Strain relief 230 V	0950	
Strain relief 115V	0950.1	
Warning label	1017	
Dynamic label	1027	
Label w/ serial number 230 V	1065	
Label w/ serial number 115 V	1066	
bearing holder + ring	1189	
Variable speed control board 230 V	1213	
Variable speed control board 115 V	1214	
Brace screws (4)	7903	
Braces (4)	7913.F	
Lower bearing assembly	7916	
Variable speed control button	8609	
Power cord (2 cords) 230 V	9011	
Stator screws (2)	9023	
Self-lubricating ring	9025	
Power cord 115 V	9040	
Power cord (Australian)	9066	
Power cord (English)	9067	
Cutter blade w/ screws	9213	
Handle screws (3)	9502	
Shaft	9809	
Switch protector	9813	
Upper motor casing (w/ carbon brushes holder)	9817	
Fan	9818	
Rotor 230 V	9819	
Rotor 115 V	9819.1	
Stator 230 V (w/ carter, carbon brushes holder)	9820	
Stator 115 V (w/ carter, carbon brushes holder)	9820.1	
Complete handle w/ slot for speed control knob 230 V	9830	
Complete handle w/ slot for speed control knob 230 V	9830.1	
Lower half handle (label side) 230V	9831	
Upper half handle (label side) 115V	9831.1	
Upper half handle	9832	
Foot assembly (tube + housing + bell + bearing)	9835	
Motor & shaft housing	9837	
Complete foot assembly	9838	
Lower bearing screws (3)	9902	

PMX 83 MIXER

Parts list



Code


Carbon brushes (2)	0514	
Ball bearing	0601	
Self-lubricating ring	0604	
Waterproof seal	0607	
O. ring	0611	
Motor self-lubricating ring	0829	
Hook	0860	
Stainless steel bell	0833	
Non-locking switch	0908	
Capacitor	0909	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Braces (4)	7913M	
Complete handle 230 V	8301	
Complete handle 115 V	8301.1	
Handle only w/ screws	8302	
Power cord 230 V	8303	
Power cord (English)	8303.1	
Power cord 115 V	8303.2	

Parts list

Code

Power cord (Australian)	8303.3	
Complete Motor 230 V	8304	
Complete Motor 115 V	8304.1	
Rotor 230 V	8304.12	
Rotor 115 V	8304.13	
Stator 230 V	8304.22	
Stator 115 V	8304.23	
Shaft	8309	
S.S. lower ball bearing assembly	8310	
Motor & shaft housing	8311	
Cutter blade w/ screw	8313	
Upper motor casing (w/ carbon brushes holder)	8315	
Lower motor casing	8317	
Handle cover + screws	8318	
handle casing + screws	8319	
Deflector	8320	
Ground wire	8321	
Screws w/ ground washer	8322	
Fan	8323	






Parts list

Code



Carbon brushes (2)	0514	
Ball bearing	0601	
Waterproof seal	0607	
Squeezing washer	0726	
Wall bracket	089959	
Non-locking switch	0908	
Strain relief 230 V	0950	
Strain relief 115V	0950.1	
Capacitor	0972.1	
Warning label	1017	
Dynamic label	1027	
Label w/ serial number 230 V	1063	
Label w/ serial number 115 V	1064	
Bearing holder + seal	1189	
Speed variator (option) (230V)	1213	
Speed variator (option) (115V)	1214	
Brace screws (4)	7903	
Braces (4)	7913.F	
Lower ball bearing assembly	7916	
Shaft	8309	
Cutter blade w/ screw	8313	
Power cord 230 V	9011	
Stator screws (2)	9023	
Ball bearing ring	9025	
Power cord 115 V	9040	
Power cord (Australian)	9066	
Power cord (Australian)	9067	
Handle screws (3)	9502	
Complete handle 230 V	9810	
Complete handle 115 V	9810.1	
Lower half handle w/ label 230 V	9811	
Lower half handle w/ label 115 V	9811.1	
Upper half handle	9812	
Switch protector (2)	9813	
Motor & shaft housing + bearing	9816	
Upper motor casing (w/ carbon brushes holders)	9817	
Fan	9818	
Rotor 230 V	9819	
Rotor 115 V	9819.1	
Stator 230 V (w/ carter, carbon brushes holders)	9820	
Stator 115 V (w/ carter, carbon brushes holders)	9820.1	
Complete foot assembly	9821	
Shaft, lower ball bearing & cutter assembly	9836	
Lower bearing screws (3)	9902	




Parts list

Code

Carbon brushes (2)	0514	
Ball bearing	0601	
Squeezing washer	0726	
Wall bracket	0880	
Non-locking switch	0908	
Capacitor	0909	
Strain relief 230 V	0950	
Strain relief 115V	0950.1	
Warning label	1017	
Dynamic label	1027	
Label w/ serial number 230 V	1071	
Label w/ serial number 115 V	1072	
Variable speed control board 230 V	1213	
Variable speed control board 115 V	1214	
Brace screws (4)	7903	
Braces (4)	7913.F	
Variable speed control knob	8609	
Power cord 230 V	9011	
Stator screws (2)	9023	
Self-lubricating ring	9025	
Coupler for armature	9028	
Power cord 115 V	9040	
Handle screws (3)	9502	
Switch protector	9813	
Upper motor casing	9817	
Fan	9818	
Rotor w/ o coupling 230 V	9819	
Rotor w/o coupling 115 V	9819.1	
Stator 230 V w/ carter, carbon brushes holders	9820	
Stator 115 V w/ carter, carbon brushes holders	9820.1	
Upper half handle	9832	
Complete handle 230 V	9840	
Complete handle 115 V	9840.1	
Lower half handle w/ label 230 V	9841	
Lower half handle w/ label 115 V	9841.1	
Aluminium carter + ball bearing	9842	
BM 250 Motor block (see machine catalogue)	AC005	






PMF - PMDH 250 mixer tool

Parts list

Code

Ball bearing	0601	
Waterproof seal	0607	
Bearing holder + seal	1189	
Lower ball bearing assembly (w/ o screws)	7916	
Cutter blade (w/ screw)	8313	
Coupling casing + pins	9051	
Tube assembly + bearing	9843	
Shaft & coupling sleeve	9844	
Shaft, lower bearing & cutter assembly	9845	
Lower bearing screws (3)	9902	
M 250 Complete Mixer tool (see machine catalogue)	AC006	



PMF 250 whisk tool

Parts list

Code


Ball bearing	0601	
Waterproof seal for whisk	0608	
Pin 3 X 20	0744	
Pin 3 X 14	0745	
Brace screws (4)	7903	
Holder + plastic ejector + seal	8612	
Plastic ejectors (pair)	8613	
Reduction gear assembly	9034	
Lower casing w/ o middle gear	9046	
Central double gear & shaft	9048	
Single gear (2) + pin	9049	
Upper plastic casing	9050	
Coupling casing + pin	9051	
Equipped upper shaft	9055	
Complete upper casing	9057	
Whisks (2)	9846	
F 250 Complete whisk tool (see machine catalogue)	AC007	


MX 79 MIXER

Parts list

Code

Sleeve	0415	
Carbon brushes (2)	0504	
Ball bearing	0601	
Waterproof seal	0607	
O. ring	0610	
Squeezing washer	0726	
Rocking switch	0903	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Complete handle	7901	
Brace screws (4)	7903	
ID plate 230 V	7904M	
ID plate 115 V	7904M.1	
Motor housing w/ carbon brush holder	7905	
Motor 230 V	7908	
Motor 115 V	7908.1	
Rotor with fan 115 V	7908.11	
Rotor with fan 230 V	7908.12	
Stator 115 V	7908.21	
Stator 230 V	7908.22	
Power cord 230 V	7911M	
Power cord 115 V	7911M.1	
Power cord (English)	7911M.2	
Power cord (Australian)	7911M.3	
Ball bearing ring	7912	
Brace (4)	7913M	
Foot assembly w/ lower bearing assembly	7914	
Shaft & coupling sleeve	7915	
Lower bearing assembly	7916	
Cutter blade w/ screw	7917	
Capacitor	7931	
Fan	7933	
Shaft, lower bearing & cutter assembly	7934	
Handle top w/screw	7938	
Lower bearing screws (3)	7950	
Lower bearing screws (3)	9902	





Parts list

Code


Carbon brushes (2)	0523	
Ball bearing	0601	
Waterproof seal	0607	
O. ring	0610	
Squeezing washer	0726	
Motor self-lubricating ring	0829	
Fan	0856	
Hook	0860	
Non-locking switch	0908	
Capacitor	0909	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Brace (4)	7913M	
Shaft	7915	
Lower bearing assembly	7916	
Cutter blade w/ screw	7917	
Shaft, lower bearing & cutter assembly	7934	
Lower bearing screws (3)	7950	
Complete handle 230 V	8301	
Complete handle 115 V	8301.1	
Handle only w/ screws	8302	
Power cord 230 V	8303	
Power cord (England)	8303.1	
Power cord 115 V	8303.2	
Power cord (Australia)	8303.3	
Brace screws (4)	8317	
Lower motor casing	8318	
Cover for handle	8319	
Ground wire	8321	
Screws w/ ground washer	8322	
Motor 230 V	8504	
Motor 115 V	8504.1	
Rotor 230 V	8504.12	
Rotor 115 V	8504.13	
Stator 230 V	8504.22	
Stator 115 V	8504.23	
Upper motor casing (w/ carbon brushes holder)	8510	
Foot assembly w/ lower ball bearing assembly	8512	


MX 91 MIXER

Parts list

Code

Motor brushes (2)	0504
Ball bearing	0601
Waterproof seal	0607
Squeezing washer	0726
Lock button return spring	0767
Safety button return spring	0768
Wall bracket	0881
Strain relief 230 V	0950
Strain relief 115 V	0950.1
Switch (230 V / 115 V)	0965
Capacitor	0972
Capacitor + filter	0972.1
Warning label	1017
Dynamic label	1027
Label w/ serial number 230 V	1028
Label w/ serial number 115 V	1029
bearing holder + seal	1186
Lower bearing assembly	7916
Cutter blade	7917
Fan	7933
Lower bearing screws (3)	7950
Brace screws (4)	8317
Upper half handle (button side)	9002
Safety switch	9005
Locking switch	9007
Rotor 115 V	9008.11
Rotor 230 V	9008.12
Plug	9009
Control lever	9010
Power cord 230 V	9011
Handle screws (4)	9014
Motor housing brush holder	9015
Stator 230 V	9016
Stator screws (2)	9023
Ball bearing ring	9025
Braces (4)	9026
Stator 115 V	9038
Power cord 115 V	9040
Carbon brush wires 230 V	9043
Power cord (Australian)	9066
Power cord (English)	9067
Complete handle w/ power cord 230 V	9100
Complete handle w/ power cord 115 V	9100.1
Half handle, label side (230V)	9101
Half handle, label side (115V)	9101.1
Speed control knob	9112
Complete foot assembly	9129
Foot assembly w/ bearing assembly	9130
Fitted shaft	9131
Carbon brush wires 115 V	9143
Shaft, lower bearing & cutter assembly	9164
Lower bearing screws (3)	9902





Parts list

Code

Motor brushes (2)	0504	
Ball bearing	0601	
Waterproof seal	0607	
Squeezing washer	0726	
Safety button return spring	0768	
Wall bracket	0862	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Filter	0999.20	
Warning label	1017	
Dynamic label	1021	
Label w/ serial number 230 V	1067	
Label w/ serial number 115 V	1068	
bearing holder + seal	1186	
Micro switch	1237	
Power on indicator light 230 V	1241	
Power on indicator light 115 V	1241.1	
Control lever	2001	
Safety control lever	2002	
Circuit board 230 V (4 switches + capacitor)	2003	
Circuit board 115 V (4 switches + capacitor)	2003.1	
Upper half handle	2004	
Lower half handle	2005	
Motor housing brush holder	2006	
Complete foot assembly	2007	
Speed control plug	2008	
Foot assembly w/ bearing assembly	2009	
Complete handle w/ power cord 230 V	2010	
Complete handle w/ power cord 115 V	2010.1	
Stator 230 V	2011	
Stator 115 V	2011.1	
Power cord 230 V > 2002	2012	
Power cord 115 V > 2002	2012.1	
Power cord (English) > 2002	2012.2	
Power cord (Australian) > 2002	2012.3	
Brace screws (4)	7903	
Lower bearing assembly	7916	
Cutter blade w/ screw	7917	
Fan	7933	
Rotor 115 V	9008.11	
Rotor 230 V	9008.12	
Power cord 230 V < 2002	9011	
Handle screws (4)	9014	
Field brace screws (2)	9023	
Ball bearing ring	9025	
Braces (4)	9026	
Power cord 115 V < 2002	9040	
Carbon brush wires 230 V	9043	
Power cord (Australian) < 2002	9066	
Power cord (English) < 2002	9067	
Fitted shaft	9131	
Carbon brush wires 115 V	9143	
Shaft, lower bearing & cutter assembly	9164	
Lower bearing screws (3)	9902	
Safety button	45710	


MDH 460 DETACHABLE MIXER


Motor

Parts list

Code

Carbon brushes (2)	0504	
Ball bearing	0601	
Squeezing washer	0726	
Lock button return spring	0767	
Safety button return spring	0768	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Switch	0965	
Capacitor	0972	
Capacitor + filter	0972.1	
Warning label	1017	
Dynamic label	1027	
ID label 230 V	1054	
ID label 115 V	1055	
Fan	7933	
Brace screws (4)	8317	
Half handle (button side)	9002	
Safety button	9005	
Lock button	9007	
Rotor 115 V	9008.11	
Rotor 230 V	9008.12	
Plug	9009	
Control lever	9010	
Power cord 230 V	9011	
Handle screws (4)	9014	
Motor housing brush holder	9015	
Stator 230 V	9016	
Field brace screws (2)	9023	
Lower aluminum housing	9024	
Ball bearing ring	9025	
Brace (4)	9026	
Coupler for armature	9028	
Stator 115 V	9038	
Power cord 115 V	9040	
Ground wire 230 V	9043	
Power cord (Australian)	9066	
Power cord (English)	9067	
Speed control plug	9112	
Ground wire 115 V	9143	
Complete handle 230 V	9900	
Complete handle 115 V	9900.1	
230 V Half handle (label side)	9903	
115 V Half handle (label side)	9903.1	





Mixer foot for MDH 460 / 2000

Parts list

Code

Ball bearing	0601	
Waterproof seal	0607	
Bearing holder + seal	1186	
Lower ball bearing assembly	7916	
Cutter blade w/ screw	7917	
Shaft, lower bearing & cutter assembly	9004	
Shaft	9031	
Coupler for armature + pin	9051	
Tube assembly	9901	
Bearing support screws (3)	9902	
M 90 Complete Mixer tool (see machine catalogue)	AC002	


Wall bracket

Parts list

Code

Wall bracket	0880	
--------------	------	--

DYNATURBO GP 2000



Parts list

Code


Ball bearing	0601	
Pin	0744	
Complete shaft w/ bearing and coupling cage	6301	
Complete tube w/ black tip	6302	
Complete lever (pad support, self lubricating bronze ring, toric washer)	6303	
Stainless steel cream bell	6304	
Stainless steel fruit bell	6305	
Stainless steel knife	6306	
Knife key	6307	
Shaft key	6308	
Toric washer	6309	
Self lubricating ruff bronze ring	6310	
Level (stainless steel only)	6311	
Waterproof ring	6312	
Compling cage	9051	
Black tip	9847	

Motor

Parts list

Code



Carbon brushes (2)	0504	
Ball bearing	0601	
Squeezing washer	0726	
Safety button return spring	0768	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
C.E.M. Filter	0999.20	
Warning label	1017	
Dynamic label	1021	
ID label 230 V	1075	
ID label 115 V	1076	
Micro switch	1237	
Power on indicator light 230 V	1241	
Power on indicator light 115 V	1241.1	
Control lever	2001	
Control lever protector	2002	
Circuit board 230 V (4 switches + capacitor)	2003	
Circuit board 115 V (4 switches + capacitor)	2003.1	
Half handle (button side)	2004	
Half handle (label side)	2005	
Motor housing brush holder	2006	
Speed control plug	2008	
Complete handle 230 V	2010	
Complete handle 115 V	2010.1	
Stator 230 V	2011	
Stator 115 V	2011.1	
Power cord 230 V > 2002	2012	
Power cord 115 V > 2002	2012.1	
Power cord (English) > 2002	2012.2	
Power cord (Australian) > 2002	2012.3	
Lower aluminum housing	2020	
Speed variator knob	2021	
Complete handle 230 V with variator (from N°040132)	2022	
Complete handle 115 V with variator (from N°040132)	2022.1	
Speed variator 230 V	2023	
Speed Variator 115 V	2023.1	
Brace screws (4)	7903	
Fan	7933	
Rotor 115 V	9008.11	
Rotor 230 V	9008.12	
Power cord 230 V < 2002	9011	
Handle screws (4)	9014	
Field brace screws (2)	9023	
Motor ball bearing sleeve	9025	
Brace (4)	9026	
Coupler for armature	9028	
Power cord 115 V < 2002	9040	
Carbon brush wires 230 V	9043	
Power cord (Australian) < 2002	9066	
Power cord (English) < 2002	9067	
Carbon brush wires 115 V	9143	
Safety cover	45710	



Parts list

Code


Motor 230 V	0542	
Waterproof seal	0607	
Safety button return spring	0768	
Wall bracket	0862	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Warning label	1017	
Dynamic label	1021	
Label w/ serial number 230 V	1089	
Bearing holder + seals	1186	
Micro switch	1237	
Power on indicator light 230 V	1241	
Control lever	2001	
Safety control lever	2002	
Circuit board 230 V (4 switches + capacitor)	2003	
Upper half handle (button side)	2004	
Upper half handle (label side)	2005	
Power cord 230 V	2012	
Power cord (English)	2012.2	
Power cord (Australian)	2012.3	
Variable speed knob	2021	
Complete handle	2050	
Upper motor casing	2051	
Silent block washer	2052	
Complete foot assembly	2053	
Regulation circuit board	2054	
Braces (4)	2055	
Centering ring	2056	
Foot assembly	2057	
Brace screws (4)	7903	
Lower bearing assembly	7916	
Cutter blade w/ screw	7917.1	
Handle screws (4)	9014	
Fitted shaft	9131	
Shaft, lower bearing & cutter assembly	9164	
Lower bearing screws (3)	9902	
Safety button	45710	




Nomenclature des pièces


Code

Carbon brushes (2)	0504	
Ball bearing	0601	
Waterproof seal	0607	
Squeezing washer	0726	
Wall bracket	0862	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Warning label	1017	
Dynamic label	1021	
ID label 115 V	1097	
ID label 230 V	109915	
Control lever	2001	
Safety control lever	2002	
230 V electronic circuit (variator + regulator circuit + control circuit)	2003DSC	
115 V electronic circuit (variator + regulator circuit + control circuit)	2003.1DSC	
Upper half handle (button side)	2004	
Upper half handle (label side)	2005	
Motor housing brush holder	2006DSC	
Complete foot assembly	2007	
Foot assembly	2009	
Stator 230 V	2011DSC	
Stator 115 V	2011.1DSC	
Power cord 230 V	2012	
Power cord 115 V	2012.1	
Power cord (English)	2012.2	
Power cord (Australian)	2012.3	
Variable speed control button	2021	
Complete handle 230 V	2060	
Complete handle 115 V	2060.1	
Sensoring washer (washers, magnets, screws, small brace)	2061	
Brace screws (4)	7903	
Lower motor casing	7916	
Brace screws (4)	7917	
Fan	7933	
Rotor 115 V	9008.11DSC	
Rotor 230 V	9008.12DSC	
Handle screws (4)	9014	
Field brace screws (2)	9023	
Motor ball bearing sleeve	9025	
Braces	9026	
Carbon brush wires (2) (230 V)	9043	
Fitted shaft	9131	
Carbon brush wires (2) (115 V)	9143	
Shaft, lower ball bearing & cutter assembly	9164	
Power bearing screws (3)	9902	
Safety cover	45710	




Parts list
Code


Carbon brushes (2)	0504	
Ball bearing	0601	
Waterproof seal	0608	
Squeezing washer	0726	
Pin 3 X 20	0744	
Pin 3 X 14	0745	
Safety button return spring	0768	
Wall bracket	0881	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Switch 115 V	0965	
Capacitor	0972	
Capacitor + filter	0972.1	
ID label 115 V	1019	
ID label 230 V	1020	
Dynamic label	1027	
Brace screws (4)	7903	
Rotor 115 V	7908.31	
Rotor 230 V	7908.32	
Fan	7933	
Brace screws (4)	8317	
Holder + plastic ejector + seal	8612	
Plastic ejector (pair)	8613	
Whisk only (pair)	8615	
Half handle (button side)	9002	
Safety button	9005	
Plug	9009	
Control lever	9010	
Power cord 230 V	9011	
Variable speed control button	9012	
Handle screws (4)	9014	
Motor housing brush holder	9015	
Stator 230 V	9016	
Field brace screws (2)	9023	
Braces	9026	
Stator 115 V	9038	
Power cord 115 V	9040	
Carbon brush wires (230 V)	9043	
Power cord (Australian)	9066	
Power cord (English)	9067	
Carbon brush wires (115 V)	9143	
Lower aluminum housing	9702	
Middle gear & shaft	9704	
Output gear & shaft + Pins	9705	
Complete handle 230 V	9706	
Complete handle 115 V	9706.1	
Half handle (label side) 230 V	9710	
Half handle (label side) 115 V	9710.1	
Plate w/ 3 seals	9711	
Holder without gear	9712	
Variable speed control board 230 V	9713	
Variable speed control board 115 V	9753	




Parts list


Code

Carbon brushes (2)	0523	
Ball bearing	0601	
Waterproof seal	0608	
Squeezing washer	0726	
Pin 3 X 20	0744	
Pin 3 X 14	0745	
Motor bushing	0829	
Fan	0856	
Hook	0860	
Non-locking switch	0908	
Capacitor	0909	
Strain relief 230 V	0950	
Strian relief 115 V	0950.1	
Brace screws (4)	7903	
Brace	7913M	
Power cord 230 V	8303	
Power cord (English)	8303.1	
Brace screws (4)	8317	
Lower motor housing	8318	
Top handle screws	8319	
Ground wire	8321	
Screws with ground washers (2)	8322	
Motor housing brush holder	8510	
Complete handle 230 V	8601	
Handle only + cap + screws	8602	
Equipped motor	8604	
Variable speed control board 230 V	8608	
Variator knob w/ clips	8609	
Middle gear & shaft	8610	
Output gear & shaft	8611	
Holder + 2 plastic ejectors + 2 seals + 3 rings	8612	
Plastic ejector (pair)	8613	
Lower aluminum housing	8614	
Whisk only (pair)	8615	
Complete axles, support, cones and pignons	8616	
Stator 230 V	8617	
Rotor 230 V	8618	




Parts list
Code

Sleeve	0415	
Carbon brushes (2)	0504	
Ball bearing	0601	
Waterproof seal	0608	
Squeezing washer	0726	
Pin 3 x 20	0744	
Pin 3 x 14	0745	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Complete handle	7901	
Brace screws (4)	7903	
ID plate 230 V	7904 F	
Motor housing brush holder	7905	
Stator 115 V	7908.21	
Stator 230 V	7908.22	
Motor 230 V	7908.3	
Rotor 115 V	7908.31	
Rotor 230 V	7908.32	
Motor 115 V	7908.4	
Power cord 230 V	7911F	
Power cord 115 V	7911F.1	
Braces	7913.F	
Plate assembly with 3 bronze seals	7918	
Middle gear & shaft	7919	
Output gear & shaft	7920	
Variable speed control board	7921	
Speed control plug	7921.1	
Holder assembly w/ 3 self-lubricating rings	7922	
Plastic protector	7923	
Lower housing	7924F	
Whisk (pair)	7925	
Capacitor	7931	
Fan	7933	
Top handle w/ screws	7938	




MF 90 & MFAP 90 MIXERS

Parts list


Code

Carbon brushes (2)	0504	
Ball bearing	0601	
Squeezing washer	0726	
Lock button return spring	0767	
Safety button, return spring	0768	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Switch	0965	
Capacitor	0970	
Capacitor + filter	0972.1	
Warning label	1017	
Dynamic label	1027	
ID label 230 V	1030	
ID label 115 V	1031	
Fan	7933	
Brace screws (4)	8317	
Complete handle 230 V	9000	
Complete handle 115 V	9000.1	
Lower half handle (label side) 230 V	9001	
Lower half handle (label side) 115 V	9001.1	
Upper half handle (button side)	9002	
Safety button	9005	
Lock button	9007	
Rotor 115 V	9008.11	
Rotor 230 V	9008.12	
Plug	9009	
Control lever	9010	
Power cord 230 V	9011	
Variable speed knob	9012	
Variable speed control board 230 V	9013	
Handle screws (4)	9014	
Motor housing brush holder	9015	
Stator 230 V w/ carter, carbon brush holders	9016	
Field brace screws (2)	9023	
Lower aluminum housing	9024	
Ball bearing ring	9025	
Braces (4)	9026	
Coupler for armature	9028	
Stator 115 V w/ carter, carbon brush holders	9038	
Power cord 115 V	9040	
Carbon brush wires 230 V	9043	
Variable speed control board 115 V	9053	
Power cord (Australian)	9066	
Power cord (English)	9067	
Carbon brush wires 115 V	9143	



Parts list

Code




Carbon brushes (2)	0504	
Ball bearing	0601	
Squeezing washer	0726	
Safety button, return spring	0768	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Filter C.E.M. 230 V	0999.20	
Warning label	1017	
Dynamic label	1021	
ID label 230 V	1069	
ID label 115 V	1070	
Micro switch	1237	
Power on indicator light 230 V	1241	
Power on indicator light 115 V	1241.1	
Control lever	2001	
Control lever protector	2002	
Circuit board 230 V (4 switches + capacitor)	2003	
Circuit board 115 V (4 switches + capacitor)	2003.1	
Upper half handle (button side)	2004	
Upper half handle (label side)	2005	
Motor housing + carbon brush holders	2006	
Stator 230 V (carter + carbon brush holders)	2011	
Stator 115 V (carter + carbon brush holders)	2011.1	
Power cord 230 V > 2002	2012	
Power cord 115 V > 2002	2012.1	
Power cord (English) > 2002	2012.2	
Power cord (Australian) > 2002	2012.3	
Lower aluminum housing	2020	
Variable speed knob	2021	
Complete handle 230 V	2022	
Complete handle 115 V	2022.1	
Variable speed circuit board 230 V	2023	
Variable speed circuit board 115 V	2023.1	
Safety plug	45710	
Brace screws (4)	7903	
Fan	7933	
Rotor 115 V	9008.11	
Rotor 230 V	9008.12	
Power cord 230 V < 2002	9011	
Handle screws (4)	9014	
Field brace screws (2)	9023	
Motor ball bearing sleeve	9025	
Braces (4)	9026	
Rotor coupler	9028	
Power cord 115 V < 2002	9040	
Carbon brush wires 230 V	9043	
Power cord (Australian) < 2002	9066	
Power cord (English) < 2002	9067	
Carbon brush wires 115 V	9143	
BM 2000 motor block (see machine catalogue)	AC001	

MF 90/2000 & MFAP 90/2000 mixer tool

Parts list

Code

Ball bearing	0601	
Waterproof seal	0607	
Bearing holder + seal	1186	
Lower bearing assembly	7916	
Cutter blade w/ screw	7917	
Lower bearing screws (3)	7950	
Shaft, lower bearing & cutter assembly	9004	
Shaft	9031	
Coupling casing + pin	9051	
Tube assembly	9901	
Lower bearing screws (3)	9902	
M 90 Complete Mixer tool (see machine catalogue)	AC002	




MF 90/2000 & MFAP 90/2000 whisk tool

Parts list

Code

Ball bearing	0601	
Waterproof seal	0608	
Pin 3 X 20	0744	
Pin 3 X 14	0745	
Brace screws (4)	7903	
Holder + plastic ejector + seal	8612	
Plastic ejector (pair)	8613	
Whisk (Pair)	8615	
Reduction gear assembly	9034	
Lower casing w/ o middle gear	9046	
Central double gear & shaft	9048	
Single gear (2)	9049	
Upper plastic casing	9050	
Coupling casing + pin	9051	
Equipped upper shaft	9055	
Complete upper casing	9057	
F 90 Complete whisk tool (see machine catalogue)	AC003	




Wall bracket

Parts list

Code

Wall bracket	0880	
--------------	------	--




Parts list

Code

Waterproof seal	0609	
Rubber washer	0830	
Blade	0834	
Washer friction	0836	
Grid	0871	
Anti-friction washer	8422	
Lower bolt	8423	
Double gear with washer	8429	
Single gear & shaft	8430	
Coupling casing w/ pin	9051	
Reducing casing & seal	9054	
Equipped upper shaft	9055	
Foot assembly	9060	
Main shaft + gears	9062	
Reduction casing screws (4)	9064	
Complete reduction box	9065	

FM 90 - 91 - 92 MASTER BEATER WHISKS



Parts list


Code


Ball bearing	0601	
Double gear with washer	8429	
Middle gear & axle	8430	
Coupling casing w/ pin	9051	
Reducing casing+2 seals	9054	
Equipped upper shaft	9055	
Complete reduction box	9065	
Mono whisk / L : 300 mm	9230 a	
Mono whisk / L : 400 mm	9230 b	
Mono whisk / L : 120 mm	9230 c	
Main shaft	9231	
Lower carter	9232	
Handle + casing	9233	
Complete reduction box w/ out bowl whisk and handle	9250	

Parts list

Code

Sleeve	0415	
Carbon brushes w/ caps (2)	0504	
Ball bearing	0601	
Waterproof seal	0609	
Squeezing washer	0726	
Pin 3 x 14	0745	
Rubber washing	0830	
Fan	0835	
Washer friction	0836	
Rice grid	0842	
Push button switch	0905	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Equipped handle	7901	
Brace screws (4)	7903	
Upper carter w/ carbon brush holders	7905	
Stator 230 V	7908.22	
Stator 115 V	7908.21	
Rotor 230 V	7908.32	
Rotor 115 V	7908.31	
Power cord 230 V	7911M	
Power cord 115 V	7911M.1	
Braces (4)	7913F	
Capacitor	7931	
Fan	7933	
Handle cap w/ screws	7938	
Identification plate 230 V	8404	
Identification plate 115 V	8404.1	
Motor 230 V	8408	
Motor 115 V	8408.1	
Foot assembly	8419	
Antifriction washer	8422	
Lower bolt	8423	
Output shaft w/ gear	8428	
Double gear with washer	8429	
Middle gear & axle	8430	
Plate w/ 2 seals	8431	





Parts list

Code

Carbon brushes (2)	0504	
Ball bearing	0601	
Waterproof seal	0609	
Squeezing washer	0726	
Pin 3 x 14	0745	
Safety button return spring	0768	
Rubber washing	0830	
Fan	0835	
Washer friction	0836	
Ricer grid	0842	
Wall bracket	0881	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Switch 115 V	0965	
Capacitor	0972	
Capacitor + filter	0972.1	
Dynamic label	1027	
ID label 230 V	1056	
ID label 115 V	1057	
Rotor 115 V	7908.31	
Rotor 230 V	7908.32	
Fan	7933	
Brace screws (4)	8317	
Antifriction washer	8422	
Lower bolt	8423	
Output shaft w/ gear	8428	
Double gear with washer (from N°050025)	8429	
Middle gear & axle	8430	
Upper half handle	9002	
Safety button	9005	
Plug	9009	
Control lever	9010	
Power cord 2 cond. 230 V (from N°050025)	9011	
Handle screws (4)	9014	
Motor housing w/ carbon brush holders	9015	
Stator 230 V w/ carter carbon brush holders	9016	
Stator screws (2)	9023	
Braces (4)	9026	
Stator 115 V w/ carbon brush holders	9038	
Power cord 115 V w/ carbon brush holders (from N°050025)	9040	
Carbon brush wires 230 V	9043	
Power cord (Australian) (from N°050025)	9066	
Power cord (English) (from N°050025)	9067	
Speed control plug	9112	
Carbon brush wires 115 V	9143	
Complete handle 230 V	9700	
Complete handle 115 V	9700.1	
Complete foot assembly	9707	
Power cord + Label 230 V (from N°050025) 3 wires	9708	
Power cord + Label 115 V (from N°050025) 3 wires	9708.1	
Plate w/ 2 seals	9709	
Lower half handle (label side) 230 V	9730	
Lower Half handle (label side) 115 V	9740	

PP 97 PLUS MOTOR BLOCK

Parts list

Code


Carbon brushes	0504	
Ball bearing	0601	
Rubber washer	0726	
Safety button return spring	0768	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Switch	0965	
Capacitor (115 V)	0972	
Capacitor + filter	0972.1	
Dynamic label	1027	
Identification plate 230 V	109913	
Identification plate 115 V	109914	
Rotor 230 V	7908.31	
Rotor 115 V	7908.32	
Fan	7933	
Brace screws	8317	
Upper half handle	9002	
Security cap	9005	
Handle cap	9009	
Control lever	9010	
Power cord 230 V	9708	
Power cord 115 V	9708.1	
Handle screw	9014	
Top housing	9015	
Stator 230 V	9016	
Stator screws 230 V (2)	9023	
Stator 115 V	9038	
Carbon brush wires (230 V)	9043	
Variator cap	9112	
Carbon brush wires 115 V (2)	9143	
Lower half handle 230 V (with label)	9760	
Lower half handle 115 V (with label)	9760.1	
Lower motor housing	9761	
Complete handle w/ power cord 230 V	9765	
Complete handle w/power cord 115 V	9765.1	


PP97 plus equipped lower carter

Parts list

Code

M4 Washer	0769	
Double gear with washer	8429	
Middle gear axle	8430	
Braces	9026	
Handle support	9233	
Plate w/ 2 seals	9709	
Exit shaft w/ gear	9762	
Aluminium carter, foot and seals	9764	





PP97 plus Whisk tool

Parts list

Code


D15 Bearing	0647	
Rubber ring	079959	
Ball bearing	7912	
Mono whisk L : 300	9230 a	
Mono whisk L : 400	9230 b	
Mono whisk L : 120	9230 c	
Equipped male casing (shaft, bearing seal, ball bearing, rubber ring)	9766	

AP 97 Ricer tool

Parts list

Code

Waterproof seal	0609	
Rubber washing	0830	
Fan	0835	
Friction washer	0836	
Ricer grid	0842	
Bearing seal	7912	
Antifriction seal	8422	
Lower bolt	8423	
Equipped male casing, bearing seal, tube and complete lever assembly	9240	
Exit shaft	9241	




SMX 450 MIXER

Parts list

Code



Fan	0509	
Carbon brushes (pair)	0529	
Ball bearing	0601	
Motor ball bearing	0602	
Rubber ring	0760	
Clips	0776	
Washer & bolt for fan	0777	
Wall bracket	0862	
Rocking switch	0903	
Capacitor	0909	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Push button switch	0990	
ON/OFF label	1008	
Foot assembly (tube, bearing, assembly)	45110	
Shaft & ball bearing	45120	
Coupling sleeves	45122	
Motor & shaft drive sprocket	45123	
Fan housing	45125	
Lower bearing assembly	45130	
Brush holder w/ cap (1) 230 V	45131	
Brush holder w/ cap (1) 115 V	45131.1	
Lower motor casing	45132	
Upper motor casing	45133	
Stator 230 V	45135	
Stator 115 V	45135.1	
Rotor 230 V	45136	
Rotor 115 V	45136.1	
Stator screws (2)	45137	
Braces (4)	45138	
Brace screws (4)	45139	
ID plate	45144	
Cutter blade w/ screw	45161	
Motor 115 V	45200.1	
Motor 230 V	45200.2	



Parts list

Code

Squeezing washer (4)	45230	
Upper carter 230 V	45300	
Upper carter 115 V	45300.1	
Power cord 230 V	45320	
Power cord 115 V	45320.1	
Power cord (English)	45320.2	
Power cord (Australian)	45320.3	
Complete handle	45400	
Sleeve	45500	
Kit w/ shaft, lower bearing, coupler, cutter	45533	
Conversion kit (SMX450 to SMX500)	45600	
Perforated disc	45810	
Perforated disc w/ pin	45820	
Bearing screws for aluminium bell (3)	7950	
Lower bearing screws (3)	9902	





SMX 500 MIXER

Parts list

Code

Turbine	0509	
Carbon brushes (pair)	0529	
Ball bearing	0601	
Motor ball bearing	0602	
Spring	0760	
Clips	0776	
Washer & bolt for fan	0777	
Wall bracket	0862	
Non-locking switch	0908	
Capacitor	0909	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
bearing holder + seal	1185	
Shaft & ball bearing	45120	
Coupling sleeves	45122	
Motor & shaft drive sprocket	45123	
Fan housing	45125	
Lower bearing assembly	45130	
Brush holder w/ cap (1)	45131	
Brush holder w/ cap (1)	45131.1	
Lower motor casing	45132	
Upper motor casing	45133	
Stator 230 V	45135	
Stator 115 V	45135.1	
Rotor 230 V	45136	
Rotor 115 V	45136.1	
Stator screws(2)	45137	
Braces (4)	45138	
Brace screws (4)	45139	
Cutter blade w/ screw	45161	




Parts list
Code



Double isolation part	45126	
Motor 115 V	45200.1	
Motor 230 V	45200.2	
Squeezing washers (4)	45230	
Power cord 230 V	45320	
Power cord 115 V	45320.1	
Power cord (English)	45320.2	
Power cord (Australian)	45320.3	
Lower housing (orange plastic piece)	45501	
Upper housing (orange plastic piece)	45502	
Top housing	45503	
Sleeve & complete handle	45505	
Complete housing w/ screws	45510	
Kit w/ shaft, lower bearing, cutter	45533	
Handle cap (2)	45610	
Foot assembly	45720	
Complete foot assembly	45722	
Perforated disc	45810	
Perforated disc w/ pin	45820	
Lower bearing screws for aluminium bell (3)	7950	
Lower bearing screws (3)	9902	


SMX 502 - 600 MIXER

Parts list

Code

Fan	0509	
Carbon brushes (pair)	0529	
Ball bearing	0601	
Motor ball bearing	0602	
Rubber washer	0760	
Clips	0776	
Washer & bolt for fan	0777	
Wall bracket	0862	
Non-locking switch	0908	
Capacitor	0909	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
ID label 230 V	1048	
ID label 115 V	1049	
Bearing holder + seal	1185	
Lower bearing screws for aluminium bell (3)	7950	
Power cord 230 V	9011	
Power cord 115 V	9040	
Power cord (Australian)	9066	
Power cord (English)	9067	
Bearing support screws (3)	9902	
Shaft & ball bearing	45120	
Coupling sleeves	45122	
Motor & shaft drive sprocket	45123	
Fan housing	45125	
Double isolation part	45126	
Lower bearing assembly	45130	
Lower motor casing	45132	
Upper motor casing	45133	
Stator 230 V	45135	
Stator 115 V	45135.1	
Rotor 230 V	45136	






Parts list

Code



Rotor 115 V	45136.1	
Stator screws (2)	45137	
Braces (4)	45138	
Brace screws (4)	45139	
Cutter blade w/ screw	45161	
Motor 115 V	45200.1	
Motor 230 V	45200.2	
Squeezing washer (4)	45230	
Lower housing (orange plastic piece)	45501	
Upper housing (orange plastic piece)	45502	
Top housing	45503	
Sleeve & complete handle	45505	
Complete housing w/ screws	45510	
Kit w/ shaft, lower bearing, coupler, cutter	45533	
Handle cap (2)	45610	
Foot assembly	45720	
Locking kit	45721	
Complete foot assembly	45722	
Perforated disc	45810	
Perforated disc w/ pin	45820	




Parts list

Code

Aluminium Fan	0509	
Carbon brushes (pair)	0529	
Ball bearing	0601	
Motor ball bearing	0602	
Rubber washer	0760	
Clips	0776	
Washer & bolt for fan	0777	
Wall bracket	0862	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
ID label 230 V	1007	
ID label 115 V	1009	
Bearing holder + seal	1185	
Shaft & ball bearing	45120	
Coupling sleeves	45122	
Motor & shaft drive sprocket	45123	
Fan housing	45125	
Double isolation part	45126	
Lower ball bearing assembly	45130	
Lower motor casing	45132	
Upper motor casing	45133	
Stator 230 V	45135	
Stator 115 V	45135.1	
Rotor 230 V	45136	
Rotor 115 V	45136.1	
Stator screws (2)	45137	






Parts list

Code

Braces (4)	45138	
Brace screws (4)	45139	
Cutter blade w/ screw	45161	
Motor 115 V	45200.1	
Motor 230 V	45200.2	
Squeezing washers (4)	45230	
Top housing	45503	
Kit w/ shaft, lower bearing, coupler, cutter	45533	
Handle cap (2)	45610	
Circuit board	45620	
Circuit board	45620.1	
Plastic Fan	45633	
Top housing (orange plastic piece)	45706	
Screws control case set	45706.1	
Lower housing (orange plastic piece)	45707	
Handle cap protector (unit)	45708	
Sleeve & complete handle & label & cap	45709	
Handle cap protectors (unit)	45710	
Lower housing w/ screws	45711	
Foot assembly w/ lower bearing	45720	
Complete foot assembly	45722	
Power cord 230 V	9011.1	
Power cord 115 V	9040.1	
Power cord (Australian)	9066.1	
Power cord (English)	9067.1	
Bearing support screws (3)	9902	





SMX 600 DSC MIXER

Parts list

Code

Carbon brushes (pair)	0529	
Ball bearing	0601	
Motor ball bearing	0602	
Toric seal	0641	
Rubber washer	0760	
Clips	0776	
Washer & bolt for fan	0777	
Wall bracket	0862	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
Bearing holder + seal	1185	
ID label 230 V	1093	
ID label 115 V	1094	
Fan housing	45125	
Double isolation plate	45126	
Lower bearing assembly	45130	
Lower motor casing	45132	
Upper motor casing	45133	
Stator 230 V	45135	
Stator 115 V	45135.1	
Stator screws(2)	45137	
Braces (4)	45138	
Brace screws (4)	45139	
Cutter blade w/ screw	45161	
Squeezing washers (4)	45230	
Handle cap (2)	45610	
Circuit board 230 V	45620	
Circuit board 115 V	45620.1	
Regulation circuit board + screws + insulating part	45630	
Foot assembly w/ bearing assembly	45631	
Shaft & ball bearing	45632	
Fan DSC	45633 DSC	
DSC Complete foot assembly	45635	
Top housing (orange plastic piece)	45706	
Screws control case set	45706.1	
Lower housing (orange plastic piece)	45707	
Handle cap protector (unit)	45708	





Parts list

Code

Upper motor casing	45709 DSC	
Handle cap protector (unit)	45710	
Complete housing w/ screws	45711	
Lower housing	45831	
Rotor 230 V	45835	
Rotor 115 V	45835.1	
Motor 230 V	45836DSC	
Motor 115 V	45836.1DSC	
Sleeve & complete handle & label & cap	46000	
Ball bearing ring	7912	
Power cord 230 V	9011.1	
Motor & shaft drive sprocket	9028	
Power cord 115 V	9040.1	
Coupling casing + pin	9051	
Power cord (Australian)	9066.1	
Power cord (English)	9067.1	
Lower bearing screws (3)	9902	

Parts list

Code

Aluminium Fan	0509	
Carbon brushes (pair)	0529	
Ball bearing	0601	
Motor ball bearing	0602	
Toric seal	0641	
Rubber washer	0760	
Clips	0776	
Washer & bolt for fan	0777	
Wall bracket	0862	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
ID label 230 V	1073	
ID label 115 V	1074	
Bearing holder + seal	1185	
Fan housing	45125	
Double isolation plate	45126	
Lower bearing assembly	45130	
Lower motor casing	45132	
Upper motor casing	45133	
Stator 230 V	45135	
Stator 115 V	45135.1	
Stator screws(2)	45137	
Braces (4)	45138	
Brace screws (4)	45139	
Cutter blade w/ screw	45161	
Squeezing washer (4)	45230	
Top housing	45503	
Handle cap (2)	45610	
Circuit board 230 V	45620	
Plastic fan	45633	




Control case



45139



45503



45830




45836


45126



45138



45831




9028



45833

45840




45832



1185



45161



45706.1



45708



45706

45620


45710



45710




45707



0950


9011.1



Parts list

Code

Circuit board 115 V	45620.1	
Top housing (orange plastic piece)	45706	
Screws control case set	45706.1	
Lower housing (orange plastic piece)	45707	
Handle cap protector (unit)	45708	
Handle cap protector (unit)	45710	
Complete housing w/ screws	45711	
Sleeve & complete handle & label & cap	45830	
Lower housing	45831	
Foot assembly w/ bearing assembly	45832	
Shaft & ball bearing	45833	
Kit w/ shaft, lower bearing, coupler, cutter	45834	
Rotor 230 V	45835	
Rotor 115 V	45835.1	
Motor 230 V	45836	
Motor 115 V	45836.1	
Complete foot assembly	45840	
Ball bearing ring	7912	
Power cord 230 V	9011.1	
Motor & shaft drive sprocket	9028	
Power cord 115 V	9040.1	
Coupling casing + pin	9051	
Power cord (Australian)	9066.1	
Power cord (English)	9067.1	
Lower bearing screws (3)	9902	





SMX 800 DSC MIXER

Parts list

Code

Carbon brushes (pair)	0529	
Ball bearing	0601	
Motor ball bearing	0602	
Toric seal	0641	
Rubber washer	0760	
Clips	0776	
Washer & bolt for fan	0777	
Wall bracket	0862	
Strain relief 230 V	0950	
Strain relief 115 V	0950.1	
ID label 230 V	1098	
ID label 115 V	1099	
Bearing holder + seal	1185	
Fan housing	45125	
Double isolation plate	45126	
Lower bearing assembly	45130	
Lower motor casing	45132	
Upper motor casing	45133	
Stator 230 V	45135	
Stator 115 V	45135.1	
Stator screws(2)	45137	
Braces (4)	45138	
Brace screws (4)	45139	
Cutter blade w/ screw	45161	
Squeezing washers (4)	45230	
Handle cap (2)	45610	
Circuit board 230 V	45620	
Circuit board 115 V	45620.1	
Regulation circuit board	45630	
Fan DSC	45633 DSC	
Top housing (orange plastic piece)	45706	
Screws control case set	45706.1	
Lower housing (orange plastic piece)	45707	
Handle cap protector (unit)	45708	
Upper motor casing	45709DSC	
Handle cap protector (unit)	45710	





Parts list

Code


Complete housing w/ screws	45711	
Lower housing	45831	
Foot assembly w/ bearing assembly	45832	
Shaft & ball bearing	45833	
Rotor 230 V	45835	
Rotor 115 V	45835.1	
Motor 230 V	45836DSC 8	
Motor 115 V	45836.1DSC 8	
Complete foot assembly	45840	
Sleeve & complete handle & label & cap	45899	
Ball bearing ring	7912	
Power cord 230 V	9011.1	
Motor & shaft drive sprocket	9028	
Power cord 115 V	9040.1	
Coupling casing + pin	9051	
Power cord (Australian)	9066.1	
Power cord (English)	9067.1	
Lower bearing screws (3)	9902	

PA 96 CITRUS JUICER - DYNAJUICER

Parts list

Code

Pulp filter	0420	
Base screws (3)	0702	
Pad	0748	
Motor screw (1)	079929	
Strain relief 230 V	0950	
Strain relief 115V	0950.1	
Switch	0998	
Switch from N°70037	0998.1	
Motor holder + waterproof ring	9601	
Power cord 230 V	9602	
Power cord 115 V	9602.1	
Power cord (English)	9602.2	
Power cord (Australian)	9602.3	
Motor + capacitor + shaft 230 V	9603	
Motor + capacitor + shaft 115 V	9603.1	
Upper ring	9604	
Top orange container	9605	
Centrifuge cone	9606	
Base	9607	





SM 4/6/8/10/12 MIXER SUPPORTS

Parts list

Code

Tightening knob	0701	
Tightening knob	0707	
Plastic caps	45610	
Plastic holder for tube	45900	
Orange half moon + screws + washer	45900.1	
60 mm width bracket	45901	
20 mm width bracket	45902	





Parts list

Code


Circlips	0758	
Fork break nut	0784	
Wing nut	0785	
Fork axle	0883	
Connecting rod axle	0884	
Blade axle	0885	
Thickness wedge	0886	
Connecting rod	0889	
Knife blade	0891	
Tray	1190	
Fork	3700	
Connecting rod concave washer	079933	
Fork concave washer	079934	
Brake nut washer	079935	
Fork washer	079936	
Blade plastic washer	079937	

GM93 MIXER

Parts list

Code

Motor 230 V	0505	
Motor 115 V	0518	
Waterproof seal	0620	
Lower or upper ball bearing	0621	
Transmission belt	0625	
Plastic handle	0790	
Pole	0899.14	
Hood pole	0899.15	



Parts list

Code

Side hood	0899.31	
Magnetic switch	0981	
Wheel with brake	9301	
Front hood	9303	
Power cord (380V)	9305	
Hood screw w/ plastic washer (unit)	9306	
Switch w/ control box	9307	
Switch w/ control box	9307.1	
Back hood	9308	
Motor pulley	9310	
Squeezing handle	9311	
Level adjustment handle	9312	
Shaft pulley	9314	
Foot assembly	9316	
Main shaft	9317	
Lower shaft	9318	
Cutter blade	9322	
Rubber holders (3)	9325	
Fork	9326	
Frame	9327	
Front wheel	9328	

EM 98 ELECTRIC SALAD SPINNER

Parts list


Code

Self-lubricating ring	0603
Handle screw (ea)	0720
Handle	0782
Friction washer	0787
Motor housing screws	079917
Switch	0905
Switch protector	0905.1
Strain relief 230 V	0950
Strain relief 115 V	0950.1
Power cord 230 V	0966
Power cord 115 V	0967
Power cord (english)	0973
Power cord (Australian)	0974
Outside basket	2801
Inside basket	P2802
Cover w/ o small cover, handle & gear	2804
Axle for outside basket	2810
Axle (including screw)	2814
Motor housing 230V (with label)	3001

Nomenclature des pièces

Code

Motor housing 115V (with label)	3001.1
Big gear	3002
Gear housing protector	3003
Motor 230 V (+ capacitor)	3004
Motor 115 V (+ capacitor)	3004.1
Motor plate	3005
Small gear	3006
Axle, big gear	3007
Motor screws	079929



Parts list E 10


Code

Outside basket	1801
Inside basket	P1802
Complete cover	1803
Cover w/ o small cover, handle & gear	1804
Handle only	1809
Axle for outside basket	1810
Small cover with handle & gear	1812
Axle	1814
Small cover (w/ o handle & drive gear)	2805
Perforated drive gear + pin	2806
Large gear	2807
Small gear	2808
Pin	2811
Axle for drive & small gear	2813
Set of gears (2806, 2807, 2808, 2811)	2815.1
Handle screws (4)	9014
Orange plastic nuts (4)	9014.P
Stainless steel pins (M4x25) (4)	9014.G

Parts list E 20

Code

Outside basket	2801
Inside basket	P2802
Complete cover	2803
Cover w/ o small cover, handle & gear	2804
Small cover (w/ o handle & drive gear)	2805
Perforated drive gear + pin	2806
Large gear	2807
Small gear	2808
Handle only	2809
Axle for outside basket	2810
Pin	2811
Small cover with handle & gear	2812
Axle for drive & small gear	2813
Axle	2814
Set of gears (2806, 2807, 2808, 2811)	2815.1
Handle screws (4)	9014
Orange plastic nuts (4)	9014.P
Stainless steel pins (M4x25) (4)	9014.G





MANUAL SALAD SPINNER E 20 "SEALED COVER"

Parts list

Code


Waterproof seal 14 x 24 x 7	0644	
Waterproof seal 25 x 27 x 6	0645	
O. Ring	0646	
Screws TBF 3.9 x 14	079958	
Outside basket	2801	
Perforated drive gear + pin	2806	
Large gear	2807	
Small gear	2808	
Axle for outside basket	2810	
Pin for large gear	2811	
Axle for drive & small gear	2813	
Axle	2814	
Set of gears (2806, 2807, 2808, 2811, 2822)	2815.2	
Handle only	2820	
Small cover (w/ o handle & drive gear)	2821	
Output small gear	2822	
Equipped cover (O. Ring + Waterproof seal	2823	
Coupling sleeve	2824	
Inside basket	2825	
Small cover with handle & gear	2826	
Complete cover	2827	
Screws (4)	9014	


2825



2810

2801







Parts list

Code

Mounting support (unit)	3507	
Foot	3508	
Suction cup (unit)	3512	
Self-lubricating ring (unit)	3523	
Circlips 18	3524	
Handle pin 4X18	3525	
Crank handle and pin	3526	
Cone shape gear and pin	3527	
Screw on button	3600	
Smooth cone shape gear	3607	
Plastic ball bearings	3608	
Handle (crank) assembly kit	3609	
Lower plate with screws (6) + self-lubricating ring	3610	
Upper cover casing	3611	
Pusher	3612	
Blockage sheet + screws (4)	3613	
Hollow axle	3614	
Roller axle	3615	
Support with screws (2)	3616	
Roller	3617	
Disc holder	3618	
Cutter pin	3619	
Axle assembly for disc holder	3620	





Parts list


Code


Lower grid 7 mm	3467	
Lower grid 14 mm	3468	
Lower grid 8,5 mm	3485	
Lower grid 17 mm	3486	
Lower grid 10 mm	3497	
Handle assembly kit	3500	
Chute	3501	
Long cutter blade complete	3504	
Short cutter blade complete	3504 c	
Knife plastic holder	3504.1	
Bottom unit	3505	
Top unit w/ seal	3506	
Mounting support (unit)	3507	
Foot	3508	
Intermediate plate assembly	3509	
Pusher 8,5 mm	3510	
Blockage sheet and screws	3511	
Suction cup (unit)	3512	
Cutter blade axle	3513	
Cutting grid axle + bearings	3514.1	
Self-lubricating ring 9/12/10	3515	
Self-lubricating ring C12/17/12	3516	
Self-lubricating ring 10/14/10	3517	
Self-lubricating ring C14/18/14	3518	
Double gear and pin	3519	
Right gear and pin	3520	
Ball bearing (unit)	3521	
Hollow axle	3522	
Self-lubricating ring (unit)	3523	
Circlips 18	3524	
Pin	3525	
Crank handle and pin	3526	
Cone shaped gear and pin	3527	
Clips (3)	3528	
Upper grid 7 mm	3567	
Upper grid 14 mm	3568	
Upper grid 8,5 mm	3585	
Upper grid 17 mm	3586	
Upper grid 10 mm	3597	
Pusher 7 mm	3867	
Pusher 10 mm	3897	

Parts list

Code

Ball bearing	0601	
Base screws (4)	9014	
Coupling + pin	9051	
Upper shaft assembly	9055	
Complete adaptor	9070	
Cover	9071	
Knife assembly	9072	
Dynacutter Bowl	9073	
Knife cone support	9074	
Inner assembly + ball bearing	9075	
Bowl pivot	9076	
Handle	9077	
Handle screws	9078	
Adaptator + seal + sticker	9080	
Output shaft w/ gear	9081	
Middle gear + shaft	9082	
Complete adaptor base	9083	
Axle 8x40	089948	
Inferior blade	089949	
Inferior serrated blade	089949D	
Superior blade	089950	
Superior serrated blade	089950D	






MULTI-FUNCTION FOOD PREP SYSTEM - VS ATTACHMENT

Parts list

Code


Ball bearing	0601	
Plate screws (4)	9014	
Coupling casing + pin	9051	
Equipped upper shaft	9055	
Stainless steel bowl	9073	
Round vegetable pusher	9084	
Complete lid	9085	
Slicing disc	9086	
Ejector disc	9087	
Base	9088	
Round shaped handle	9089	
Vegetable pusher	9090	
Lid only	9091	
Intermediate gear	9092	
Output gear + shaft	9093	
Plate + ball bearing	9094	
M8 X 16 screws	079947	
Hexagonal shaft	089964	




9086




9087



9088




9073



9086 Slicing disc

Parts list



Code



9086 Slicing disc		
Coupler screws	9502	
Twelve-sided hub	9095	
Axle for slicing or grating disc	9096	
Disc for French Fries		
Screws for hexagonal hub	9502	
Hexagonal hub	9095.a	
French Fries disc	9175	
Axle for slicing disc	9172	
Nut	9174	
9170 Disc for cubes		
Screws for hexagonal hub	9502	
Hexagonal hub	9095.a	
Slicing disc	9171	
Axle for slicing disc	9172	
Cubes disc	9173	
Nut	9174	

Disc for French Fries

9170 Disc for cube



International distribution:

NORTH AMERICAN DISTRIBUTION

Tel.: +1-800-267-7794 - +1-514-956-0127
Fax: +1-877-668-6623 - +1-514-956-8983
e-mail: info@dynamicmixers.com

FOB USA: Dynamic

2301 Sturgis Road - Oxnard, CA 93030
www.dynamicmixersusa.com

FOB CANADA: Dynamic

3227 Boul. pitfield - Saint-Laurent
Québec - H4S-1H3
www.dynamicmixers.ca

GERMANY: Dynamic

Groupe NADIA GMBH
Auenheimer Straße 26a
77694 KEHL - Neumühl
Tel.: +49 (0)7851 / 89 82 58
Fax: +49 (0)7851 / 89 82 59
e-mail: info@dynamicmixer.de
www.dynamicmixer.de

SATELLITE OFFICES:

SAINT-MARTIN - Tel.: 05 90 52 88 44
TAHITI (Polynésie Française) -
Tel.: (689) 70 49 64

SPAIN: Dynamic

GUERRERO CLAUDE
Poligono Can Calderon
C/Mare de deu Nuria 25
Nave 1-1 / 08830 Sant Boi de Llobregat
(ESPAÑA)
Tel.: +34 93 662 81 61
Fax: +34 93 662 75 21
e-mail: info@guerreroclaude.com
www.guerreroclaude.com

ITALY: Dynamic

MELCOM s.r.l. - Via Sommacampagna, 20/L
37137 VERONA (ITALIA)
Tel.: +39-045-8647035
Fax: +39-045-8626141
www.melcom.it

AUSTRALIA: Dynamic

Bonn Appliances
4/40 Rivergate Place
Murarrie - Qld 4172 - AUSTRALIA
Tel.: 07-3390 4185
Fax: 07-3393 9508
www.bonnappliances.com

DYNAMIC FRANCE:

S.A.S. au capital de 216.780 Euros - RCS 416 450 435 - La Roche-sur-Yon
B.P. 57 - Z.i. du Puy Nardon - 85290 MORTAGNE-sur-SEVRE
TEL. 33 (0)2 51 63 02 72 - FAX 33 (0)2 51 63 02 73
Site Web: www.dynamicmixers.com
e-mail: contact@dynamicmixers.com

Distributed by :



The original!